

Aufbauanleitung "IsoFrame Wave" Seil-Spann-System Set

Mounting instruction

Brochure holder system

- Uncut wires
IS-9310 Wire system with 4 meter (157.5") wires
- Pre-cut wires
IS-9311 Wire system for Midi 2470 mm (97.2") panels
IS-9312 Wire system for Maxi 2270 mm (89.4") panels
- IS-9318 Brochure holders A4 / US letter with 4 connectors

Please observe: This system can only be used with a straight Compact or Straight graphic wing module



Mounting instruction

- 1 Push in the small H-profile at the top of the beam and then mount the extra beam into that profile.
- 2 Mount this assembly at top of the posts.
- 3 Attach the graphic panel and adjust the base beam so that its bottom edge aligns exactly with the bottom edge of the graphic.
- 4 Hook the top connector of the wire assembly to the top beam.
- 5 Mount the first bottom connector.
- 6 Press the bottom fitting of the wire assembly into the connector until the wire is tight. Repeat this process with the top fitting.
- 7 Attach the four identical grip connectors to the brochure holder, evenly spaced. Do not overtighten.
- 8 Remove the side screws in the grip connectors, position the wire inside the grooves, and reinstall the side screws.
- 9 You can now attach more brochure pockets.